

Work Order ID 151337***151337***

Page 1

Thursday, November 10, 2016 10:04:10 AM

Item ID: D350-600-242 REPAIR

Accept

N900040100Setup Start ***NS1***

Revision ID:

Stop ***NS2***

Item Name: Spacepod™ Fwd Opening RH AS350 / AS355

Start Date: 9/27/2016 Start Qty: 1.00 ***1***

Cust Item ID:

Required Date: 9/28/2016 Req'd Qty: 1.00 ***1***

Customer: CADVA02

Reference: RMA RA112389

Approvals: Process Plan: W Date: _____ Tooling: _____ Date: _____Run Start ***NR1***

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

100

0.00

100

QC

Quality Control

Memo

INSPECT RA112389

Cancel

See RA112389-1
RA112389-2

W 16-11-10

Wednesday, November 09, 2016 3:15:13 PM

Parent Item: D350-600-242 REPAIR

Parent Item Name: Spacepod™ Fwd Opening RH AS350 / AS355

Start Date: 9/27/2016

Required Date: 9/28/2016

Start Qty: 1.00

Required Qty: 1.00

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D350-600-242 REPAIR

Manufactured

No

Each

0.0000

1

D350-600-242 RFPAIR

Spacepod™ Fwd Opening RH AS350 / AS355